Model PPU2100W/B
PowerPort™ Portable Charger & Battery

PLEASE READ THE INFORMATION AND FOLLOW ALL INSTRUCTIONS THOROUGHLY BEFORE USING THIS PRODUCT.

Owner's Manual

Thank you for purchasing the PowerPort Portable Charger & Battery. Please read this manual carefully. It contains important operating instructions for your Power Pack unit. Carry the small, light and convenient Power Pack with you and have a handy charger or rescue battery that works anywhere for your cell phone, PDA, MP3 player, game system or anything that can be charged via its USB cable connection. The Portable Charger & Battery kit includes the main battery unit, power USB cable for recharging the battery and connecting to your device, plus cable tips for iPod, Sony PSP and many PDA's and Mini USB for Motorola Cell Phones & other devices.

Caution:

- Do not overcharge the battery as it will shorten its life span. Disconnect the battery as soon as it is practical after charge is complete.
- Battery and cable are for dry use only. Never use near water or allow to get wet.
- Recycle or dispose of battery properly. Battery may leak or explode causing personal injury if disposed of in fire, or short circuited.
- Do not drop.
- Unplug the battery from the charge cable and all devices when not in use.

Note:

- Battery is not charged as shippedand must be charged prior to first use.
- Battery may become warm during charging or use.

Battery Status Indicator

The battery's Status Indicator works like a fuel gauge for the battery. Pressing the button on the front of the battery case will activate the LED and show if the battery needs to be recharged or not. For the most accurate reading, it is best to check the battery while not in use. For the best results, charge the unit fully before use.

Blue	OK for use
Red	Recharge

Charging Your PowerPort

Across from the USB Power output connector is the "Mini USB" connector used to charge the PowerPort unit. Use the supplied power cable and fit the Mini USB tip on the end of the cable. Plug the USB end of the cable into any computer USB port or other USB PowerPort like the one available on the Mach1 Fusion USB. Plug the other end of the cable into the "IN" socket on the end of the battery. While charging, one LED of the battery's Status Indicator will light up red. When the charge has been completed the LED will turn Blue. Once the charge indicator shows the charge has completed, disconnect the battery from the USB power source and the battery is ready to use.

Note: If charging your PowerPort unit from a computer, the computer must be turned on and running.

Charging Your Device Using Your PowerPort

You can use the PowerPort to recharge your device or to power it directly to extend the run time of your device. To use the Power Pack with your device use the cable and connectors supplied, or you will need to obtain the proper USB charge/sync cable for your device (sold seperately). Simply plug the USB end of the cable into the battery socket marked OUT and connect the other end to your device. Press the status indicator button to activate the PowerPort and your device should then indicate that it is receiving power. If you are using the Power Pack to recharge your device, be sure to disconnect as soon as possible after your device is recharged to conserve the power in the Power Pack.

Specifications

Charge Input:	5VDC, 1000mA
Charge Time:	Approx. 4-6 Hours max.
Output:	5VDC, 700mA max. (7.8Wh)
Status Indicator:	2-color LED
Protection:	Over-charge, over-discharge, short-circuit
Dimensions:	3.9 x 2.4 x 0.4 in.
Weight:	~27 oz.

Limited 2 Year Warranty

This limited warranty starts from the date of original purchase and expires two years thereafter. If, during this period, any part, because of manufacturing defects or workmanship, fails to function properly under normal use it will be repaired at no charge for parts and labor or, at our option, the product will be replaced. The following is excluded: damages from delay or loss of use of equipment or damaged batteries, malfunctions resulting from misuse, tampering, unauthorized repairs, modifications or accident.

Package the unit and its accessories carefully using ample padding material to prevent damage in transit and ship it prepaid and insured to:

LENMAR ENTERPRISES, INC.
4035 Via Pescador
Camarillo, CA 93012 USA

When sending in product for service, your package should include evidence of date and place of purchase. Enclose $10.00 for shipping and handling for addresses in the U.S. and $15.00 in Canada. For outside the U.S. and Canada, freight will vary depending upon ship-to address.

Proposition 65 Notice (California)
The following statement is required in the state of California pursuant to the settlement of an action brought by the Mateel Environmental Justice Foundation against multiple electronics and appliance manufacturers

- WARNING: Handling the cord on this product will expose you to lead, a chemical known to the state of California to cause birth defects or other reproductive harm. Wash hands after handling.

For additional questions, comments or to explore other Lenmar battery solutions, visit our web site at: www.lenmar.com or call 805/384-9600 from 9AM – 5PM PST.

307-127-W r2

Lithium-Ion battery must be recycled or dispose of properly.

RECYCLE
Li-Ion
1.800.822.8837